WAGAN TECH®

Item no. 2260

6 LITER PERSONAL FRIDGE/WARMER

V2.0

User's Manual

6 Liter Personal Fridge/Warmer by Wagan Tech



WAGAN® TECH

www.wagan.com

Thank you for purchasing the 6 Liter Personal Fridge/Warmer by Wagan Tech. With normal care and proper treatment it will provide years of reliable use. Please read all operating instructions carefully before use.

USING THE 12V DC ADAPTER

1. Connect the DC power cord of the power adapter into DC socket of the cooler.
2. Start the car engine.
3. Plug the power adapter into the car lighter socket firmly.
4. Choose Heat or Cool mode with the power switch.
5. The Red light will light for warming and the green light will light for cooling.

COOLER MODE

It will take about 30 minutes to reach the maximum cooling temperature of approximately 34°F (1°C). Items can be placed in the cooler pre-chilled to assist in reaching the lowest temperature as quickly as possible. The cooler will continue to operate as long as power is supplied. Contents will stay cool for some time after the unit is disconnected or turned off, however, the temperature will rise to that of the surrounding air over time. Exercise normal cautions that you would for any food in a cooling device. The appliance is not designed for storing ice or open containers of liquids.

WARMER MODE

It will take about 60 minutes to reach the maximum warming temperature of approximately 140°F (60°C). It is recommended that items placed in the warmer be pre-heated to assist in reaching the maximum temperature as quickly as possible. The warmer will continue to operate as long as power is supplied. A built-in thermostat will cycle the unit on and off to prevent overheating. Contents will stay warm for some time after the unit is disconnected or turned off, however the temperature will drop to that of the surrounding air over time.

CLEANING AND MAINTENANCE

To clean the unit, switch the power off, unplug it from its power source and allow it to cool. Wipe the inside with a clean, damp cloth. Use mild soap with water if necessary. Do not use abrasive household chemicals to clean the appliance (e.g. Bleach, white spirits, etc.)

©2009 Wagan Corporation.
All Rights Reserved.
Wagan and wagan.com are trademarks used by Wagan Corporation.

PRODUCT SPECIFICATIONS

Capacity	6 Liters (9 Cans)
Current	3.3 Amps
Power supply	12V DC
Temperature	Thermostatically controlled
Insulation material	Polyurethane foam
Maximum Cooling	Approximately 1°C (Max. 30°C below ambient temperature)
Maximum Warming	Approximately 60°C
Brushless Motor	30,000 hour life
Power Consumption	40W

WARNINGS

- Children cannot sense the dangers caused by improper handling of electrical devices. Therefore, do not let children use this cooler/warmer except under adult supervision.
- Do not carry the cooler by the cable or pull the cable to remove the plug from the socket. Protect the cable from heat, oil, solvents, sharp objects or anything that could damage the insulation.
- Inspect the cooler cable and any extension leads used periodically for excessive wear or damage.
- Operate the unit only with the cord provided. Store the cord inside the unit to prevent misplacing it.
- Do not hold the plug with wet or moist hands.
- Unplug unit before starting the vehicle, then re-plug in the appliance after the vehicle is running as the voltage surge could damage the unit.
- Switch off the unit and wait for 30 minutes before switching from Cool to Heat mode or vice versa.
- Do not use in poorly ventilated areas. Excessive heat needs to be discharged and fresh air brought in. Good ventilation is essential to avoid overheating. The internal fuse may be damaged and lose its power if used in badly ventilated places. Do not cover the vents.
- Do not place in a sealed car or in a trunk. Never obstruct the air flow. Never use the appliance in closed rooms without a supply of fresh air.

- Remove any tar or rust. Don't plug into a lighter socket of a 24V lorry or bus. Use an adaptor when used in a lorry or bus. Use an extension cord if it is too short (10A or above, available at car accessory shops)
- Do not put any foreign objects into the fans during operation. Avoid using on grassy areas since grass may enter the fan.
- Pay special attention to the batteries when in use. Pull the plug from the power source after use. The power source may still run depending on the overheating of the batteries.
- Do not immerse the appliance or the 12V adaptor in water.
- Do not put ice or ice packs in the cooler.
- The appliance is suitable for camping use, but not when exposed to rain.
- In heating mode metal parts inside the unit become very hot. Do not touch the metal parts if the unit is being/was operated in heating mode.

DISPOSAL AND THE ENVIRONMENT

If your cooler requires replacement or is of no further use, please think of protecting the environment. Contact your local authority for advice as many have facilities for environmentally safe disposal.

©2009 Wagan Corporation.
All Rights Reserved.
Wagan and wagan.com are trademarks used by Wagan Corporation.

WAGAN Corp. Limited Warranty

All WAGAN Corporation products are warranted to the original purchaser of this product.

Warranty Duration: This product is warranted to the original purchaser for a period of one (1) Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the event of a defective item, please contact WAGAN Corporation at (800) 231-5806 to obtain a Returned Merchandise Authorization number (RMA#), and return instructions. Each item returned will require a separate RMA#. After you have received the RMA# and the return instructions from WAGAN Corporation, please follow the instructions and send the item with PREPAID SHIPPING, along with all of the required documentation, a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replace or repair the defective part.

A Returned Merchandise Authorization number (RMA#) is REQUIRED when sending in any defective item. WAGAN Corporation is not responsible for any item(s) returned without an official Returned Merchandise Authorization number. The item(s) must be returned with prepaid shipping. WAGAN Corporation is not responsible for any shipping charges incurred in returning the item(s) back to the company for repair or replacement. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.

Warranty Disclaimers: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.

Warranty Performance: During the above one (1) Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1) Year warranty period. *Updated August 2008*

Detach and return the opposite page to the address indicated.

WAGAN Corp. Limited Warranty Registration Form

☑ Please activate my limited warranty for WAGAN Corp.

Name		
Mailing address		
City		
State, Zip code		
E-mail address		
Item purchased		Item no.
Store name		
Date of purchase		
Signature		*Date*

All WAGAN Corporation Products must be registered within (30) days of purchase to activate this warranty. Mail the complete registration form, along with a copy of the original sales receipt to:

Attn. Customer Service
WAGAN Corporation
31088 San Clemente St.
Hayward, CA 94544